

## ELECTRONIC TOTAL STATION PTS-V SERIES

### OPERATING PROCEDURES OF SPECIAL FUNCTIONS

Command No.	Program Name	Page
101	Distance Stake-out	9
102	Leveling	12
103	RDM	16
104	Coordinates	19
105	Offset Point	22
106	Lot Staking	25
107	Inverse Azimuth/Distance	28
108	Traverse	31
109	Coordinate Stake-out	2
110	H. Angle Repeat	36
111	3D Cross Section	39
112	REM	42
113	Resection	45
114	Direct Stake Check	49
115	Remote Stake Check	52
116	Offset Station	55
117	Area	58
118	Scaling	61

# Operation procedures of special functions 1

This manual is a reference for the operation procedures of the special functions (18 application programs) in the manner as described below.

## 1 General pictures of measurement

This illustrates the content of the program.

## 2 Flow of the operation and conceptional drawings of the operation


This illustrates the general operational flow of each operation.

## 3 Operation procedures

This describes the actual operation procedures.

Since detailing the operation procedures of each program would cause unnecessary complexity and size, this manual shows detail for "Coordinate Stake-Out Measurement" only, as an example. Descriptions of the other programs are simplified. The guide messages, however, of each step of the operation help you to proceed in a proper manner for the other programs. We are confident, therefore, that you will be able to use the other application programs once you are familiar with the operation of "Coordinate Stake-Out Measurement" program.

The flow chart, of the operation procedures, has 3 types of information as illustrated below: those needing key operations, those not needing key operations and those expressing display status.




For further information, please contact your local Pentax Authorized dealer.

# 2 Coordinate Stake-Out Function Command No. 109


## General pictures of measurement

In coordinate stake-out measurement, coordinates can be staked out in three dimensions, based on the instrument coordinates and backsight coordinates which are already known, or on the back sight directional angle and the instrument point coordinates. The horizontal angle to the stake-out point and the horizontal distance are calculated automatically as the design values, and the difference between the calculated values read during measurement is displayed as the deviation. Also, with coordinate stake-out measurement, "s/s compensation" (scaling compensation towards the coordinates of the horizontal plane angle, or scale correction) can be carried out. (For more information on s/s Compensation, please refer to page 61.)

### General picture




### Design values and deviation





## Operation procedures and Operative illustrations


INPUT S.P  
STEP 1




1 → NEZ B.S.P  
2. AZIMUTH STEP 2



AIM B.S. POINT  
PRESS ENT STEP 3



INPUT STK.P  
STEP 4




STAKING START STEP 5

MEAS

TRACK

OK




# 4 Coordinate Stake-Out Function Command No. 109

## Operation procedures



Press number keys as [007109], and press [ENT] to access STEP 1 in the coordinate stake-out measurement.

### Step 1 Inputting the instrument coordinates (NEZ) and instrument height


1 Press [ENT] key to display the screen where the instrument coordinates "NEZ" are entered.



2 Press [CLR] key to delete the "N" data.




3 As an example, let's input a value of "-12345.890". To input the value for coordinate "N", press the number keys in the following order. [+/-] [1] [2] [3] [4] [5] [.] [8] [9] [0]. Press [ENT] key and move the cursor to [E]. Use number keypad to set.




4 Set the "E" coordinate in the same way; first press [CLR] to clear and then enter a new value for the instrument coordinate "E" using the numeric keys. Then press the [ENT] key to input the setting.

5 Finally, repeat the process for the "Z" coordinate, first pressing [CLR] and then using the numeric keys to enter a new values. Then press the [ENT] key to input the setting.





6 In the same way as for the instrument height, press [CLR] to delete the previous value, and use the numeric keys to input the new value. Pressing the [ENT] key changes the screen to the "STEP 2" screen.




- \* At STEP 2, the [CLR] key should be pressed to clear the data even if the previous value is "000.000".
- \* At STEP 5, if there is no need to enter a Z coordinate, leave the data as "000.000", or simply press the [CLR] key and then press the [ENT] key. This sets a Z coordinate of "0".

## Step 2 Inputting the backsight coordinates or the backsight azimuth angle



1 As an example, we will select a backsight azimuth angle and input a value of 123° 45' 20". Use the number "2" key to select "2. AZIMUTH ANGLE".



2 Press [CLR] key to delete the previous data set for azimuth angle, and then, using the numeric keys, input the following value: [1] [2] [3] [.] [4] [5] [2] [0]. This sets the backsight direction angle.



3 Pressing the [ENT] key stores the value and changes the screen to the "STEP 3" screen.




- \* At STEP 2, the [CLR] key should be pressed to clear the data even if the previous value is "000.000".
- \* In setting of 123° 45' 20" entered at STEP 2, a decimal is used where the degree mark would be, and no separation is made between the minutes and seconds.

# 6 Coordinate Stake-Out Function Command No. 109



## Step 3 Sighting the backsight point

Following the guide messages on the screen, sight the back-sight point and press the [ENT] key. The screen changes to the "STEP 4" screen.





## Step 4 Inputting the stake-out point coordinates (NEZ) and the prism height

1 Press the [ENT] key to bring up the screen where the staking point coordinates "NEZ" are input.





2 In the same way as for STEP 1, enter the data for the N,E, and Z coordinates.

3 When the "Z" coordinate data has been entered and the [ENT] key pressed, the screen changes to the prism height input screen.




4 Input the prism height in the same way. When the [ENT] key is pressed, the screen changes to the "STEP 5" screen.



\* At STEP 3, if there is no need to enter a Z coordinate, leave the data as "000.000", or simply press the [CLR] key and then the [ENT] key. This stores a Z coordinate of "0"


## Step 5 Starting Stake-out measurement

1 Press the [ENT] key to bring up the screen where the value entered for the staking point coordinates can be confirmed. The design values calculated using the data entered in STEP 1 to STEP 4 are displayed on the screen.




SET VALUE	
H.ANG	123° 45' 50"
	127.972 m
P-30 Oppm	OK

2 Press the [▲] key to confirm the Z value.



SET VALUE	
H.ANG	123° 45' 50"
Z	12.340 m
P-30 Oppm	OK

3 Pressing [OK] changes to the horizontal angle setting screen, with the "SET", "ANG", and "DEV" displayed.




SET :	123° 45' 50"
H.ANG ANG :	65° 43' 20"
DEV :	-58° 02' 30"
P-30 Oppm	OK

4 Rotate the instrument, using the upper H. motion, until the "DEV" reads "0" (or as close to "0" as possible), and lock the rotation of the horizontal direction of the instrument.

SET :	123° 45' 50"
H.ANG ANG :	123° 45' 50"
DEV :	0° 00' 00"
P-30 Oppm	OK

5 Press [OK] to move to the distance measurement screen, where "SET", "DST" and "DEV" are displayed.




SET :	65.430 m
DST :	0.000 m
DEV :	-65.430 m
P-30 Oppm	MEAS TRACK





# 8 Coordinate Stake-Out Function Command No. 109

6 Move the prism to the sighting direction of the telescope, and press the [TRACK] key to measure to the prism.





7 Move the prism in the direction in which the "DEV" approaches "0".

8 When the "DEV" has come close to "0", press [MEAS] key to switch to normal distance measurement. Continue measuring until you find the exact point where "DEV" becomes "0". This concludes stake-out of the No.1 point.



9 Pressing [OK] key takes you back to STEP 4. Repeat the process for the No.2 and No.3 points if there are any.




- \* If the minimum angle unit is not set to (1"/2cc), there may be times when you can not get a value that is exactly "0".
- \* When tracking the prism in STEP 6, continuous measurement is carried out once the [TRACK] key has been pressed after the ground position of the prism has been determined. Using shot measurement in normal distance measurement mode is the most efficient way to find the precise position of the prism.
- \* Each time the [▲] is pressed, the display changes in sequence from "Horizontal distance" to "Height Z" to "Horizontal design value". Data input using this function is retained in the memory when the power is turned off, and all data except the staking point coordinates can be used in common with other functions.
- \* To exit a special function, or to interrupt it and go back to the [A MODE] screen, press the [ESC] key several times, until the screen returns to the [A MODE] screen. (The number of times the [ESC] key has to be pressed varies depending on the point at which the key is pressed.)


## General pictures of measurement

With distance stake-out measurement, the difference between the input design values (specified distance) and the distance to the prism is displayed, making it easier to stake a point.

### General picture




### Design values and deviation



# 10 Distance Stake-Out Function Command No. 101

## Operation procedures and operative illustrations




- \* When the deviation is "minus", move the prism backwards, and move it forwards when the deviation is "plus" to make the deviation to "0".
- \* When interrupting the function, press [ESC] a couple of times. The screen returns to special function menu screen.


## Operation Procedures

Press number keys as [007101], and then press [ENT] to access STEP 1 of the distance stake-out function.

### Step 1 Selecting the distance to be displayed and Inputting the design values



### Step 2 Starting the measurement




\* In STEP 2, the [▲] key can also be used to change to the angle display.

# 12 Leveling Function Command No. 102

## General pictures of measurement

With the leveling measurement, the elevation of the observation point, and the horizontal distances to the bench mark and the various observation points can be calculated and displayed by entering the elevation of the bench mark (BM).

### General pictures



## Operation procedures and operative illustrations


[When selecting the new observation point]

1→NEW MEAS	LEVEL
2. STATION PT MOVE	MENU





\*Selecting "1. NEW MEAS"

BENCH MARK MEASUREMENT	STEP 1
------------------------	--------



FORESIGHT MEASUREMENT	STEP 2
-----------------------	--------



\* Any number of foresight points can be observed by repeatedly pressing [MEAS] in STEP 2. When moving the instrument, press [OK] key to register the TP after observing the point which will be the turning point.

\* Pressing [ESC] key a couple of times interrupts the function. The screen returns to the special function menu screen.

# 14 Leveling Function Command No. 102




## Operation procedures and operative illustrations

[When selecting the Instrument moved]

1→NEW MEAS	LEVEL
2. STATION PT MOVE	MENU

\*Selecting "2.STATION PT MOVE"

T.P.MEAS	STEP 1
----------	--------




\* Pressing [ESC] key interrupts the function. The screen returns to the special function menu screen.


## Operation procedures

Press number keys as [007102], and then press [ENT] key to initiate [Leveling Function]. Select "1. New Observation" with the number (1) key to access STEP 1.

### Step 1 Observing the bench mark (BM)



### Step 2 Observing the foresight point (P1)



\* If the instrument will be moved from one point to another, first select new observation, and then, after the instrument point is moved, select "Instrument Moved". If the instrument will be moved after a measurement, always make sure the last turning point (TP) is always stored.




# 16 RDM Function Command No. 103


## General pictures of measurement

With RDM measurement, the horizontal distance, vertical distance, the slope distance and the percentage of slope between the base point and the prism at the observation point are measured. The base point can be changed to any desired observation point.

### General pictures



## Operation procedures and operative illustrations



\* Use [▲] to select the desired distance mode ,horizontal distance, slope distance, vertical distance or percentage of slope, in STEP 2.


\* Pressing [ESC] key a couple of times interrupts the function. The screen returns to the special function menu screen.

# 18 RDM Function Command No. 103





## Operation procedures

Press the number keys as [007103], and press [ENT] to access RDM Function.

### Step 1 Observation of the target point



### Step 2 Observation of the distance to the target point (P1)




\* The slope that can be calculated and displayed with the RDM function is  $\pm 200.00\%$ .

\* The difference in height is indicated in  $\pm$ .

## General pictures of measurement

With coordinates measurement, the instrument point serves as the datum station, and the coordinates of any desired target point can be determined. Even if the instrument point is not used as the datum station, the coordinate values can be determined from the coordinate datum station by inputting the coordinate values of the instrument point.

### General picture



- \* When coordinates measurement is done by setting the direction angle to the backsight point, use the Inverse/Azimuth Distance Function to orient the direction angle to the backsight point before measurement.

# 20 Coordinates Measurement Function Command No. 104

## Operation procedures and operative illustrations

NEZ INPUT

STEP 1



TARGET MEASUREMENT

STEP 2

MEAS

TRACK

(NEXT POINT)

OK



Inputting instrument point coordinates




Observing

\* Pressing [ESC] key a couple of times interrupts the function. The screen returns to the special function menu screen.


## Operation procedures

Use the number keys as [007104], and press [ENT] to access Coordinates Measurement.

### Step 1 Inputting the instrument point coordinates



### Step 2 Observation of target points (P1 to Px)




\* When using a known point as the backsight point for coordinate measurement, the "Inverse Azimuth/Distance" function can be executed first, to have the azimuth angle of the backsight point already entered.

## General pictures of measurement

Offset point measurement can be used when the prism cannot be positioned because of an obstacle in the way. With this type of measurement, the target coordinates are measured indirectly.

### General picture



\* Set the base point (prism) at a ground point which is adjacent to the target and at the same distance from the instrument as the target is.

## Operation procedures and operative illustrations

INPUT S.P  
STEP 1



1 → NEZ B.S.P  
2. AZIMUTH STEP 2



AIM B.S.POINT  
PRESS ENT STEP 3








REFERENCE POINT  
MEASUREMENT STEP 4



TARGET MEASUREMENT STEP 5

(TARGET SIGHT)  
REPEAT

OK



\* Prism needs not to be positioned for the target sighting.

\* Pressing [ESC] key a couple of times interrupts the function. The screen returns to the special function menu screen.




# 24 Offset Point Measurement Function Command No. 105


## Operation procedures

Press the number keys as [007105], and press [ENT] to access STEP 1 of Offset Point Measurement function.

### Step 1 Inputting the instrument point coordinates and the instrument height



### Step 2 Inputting the backsight point coordinates or the azimuth angle of the backsight point




### Step 3 Sighting the backsight point




### Step 4 Inputting the prism height and observing the base point

Set the base point (prism) at a ground point which is adjacent to the target and at the same distance from the instrument as the target is.




### Step 5 Observing the target



**General pictures of measurement**

With the lot staking function, the design values for an input distance, or a distance between two points which have already been specified, can be divided into a number (N) of equal segments.

**General pictures**



# 26 Lot Staking Function Command No. 106

## Operation procedures and operative illustrations

1→H.DIST  
2. S.DIST  
3. V.DIST

▲ MODE

STEP 1



1→MEAS  
2. INPUT

DIST(L)

MENU








LOT STAKING

STEP 2



STAKING START

STEP 3




\* Pressing [ESC] a couple of times interrupts the function. The screen returns to the special function menu screen.


## Operation procedures

Press the number keys as [007106], and press [ENT] to access STEP 1 of Lot Staking Function.


### Step 1 Selecting the distance display



### Step 2 Calculating the N segments




### Step 3 Starting the measurement




## General pictures of measurement

With inverse azimuth/distance measurement, the azimuth angle and distance to a backsight point can be calculated and displayed by inputting known instrument point coordinates and the backsight point coordinates. The azimuth angle calculated here is displayed in the [A MODE] as the horizontal angle. The scaling function can also be used with inverse azimuth/distance measurement.

### General picture



## Operation procedures and operative illustrations




\* Pressing [ESC] key interrupts the function. The screen returns to the special function menu screen.

## Operation procedures


Press the number keys as [007107], and press [ENT] to access STEP 1 of Inverse/Azimuth Measurement Function.

### Step 1 Inputting the instrument point coordinates



\* The values for the Z coordinate are not directly related to this measurement, and can be omitted here (simply press [ENT] without entering a value).

### Step 2 Inputting the backsight point coordinates




\* The Z coordinate may be omitted.

### Step 3 Confirming the calculated values



\* When you go back to the [A MODE], the design values calculated here (the backsight point azimuth angle) will be displayed as the horizontal angle.


### Step 4 Sighting the backsight point



## General pictures of measurement

With traverse measurements, the coordinate values of a new point can be determined, based on the given "instrument point coordinates and backsight point coordinates" or the "instrument point coordinates and direction angle". There are two methods used in traverse measurements: "New Observation" and "Instrument Moved". With the "New Observation", when a new traverse is begun, the coordinates of a known point are input as the backsight point, while with the "Instrument Moved", the instrument is moved, and the coordinates of the previous instrument point are observed as the backsight point, while the coordinates of the previous new point become the instrument point. Scaling can also be used with traverse measurements.

## General picture






# 32 Traverse Measurement Function Command No. 108

## Operating procedures and operative illustrations

[When selecting the new observation]



\* Pressing [ESC] key a couple of times interrupts the function. The screen returns to the special function menu screen.

## Operation procedures and operative illustrations



[When the Instrument moved]

1 → NEW MEAS	TRV
2. STATION PT MOVE	MENU







\*Selecting "2. STATION PT MOVE"

STATION PT MOVE	STEP 1
-----------------	--------



AIM B.S.POINT	
PRESS ENT	STEP 2




\* Pressing [ESC] key a couple of times interrupts the function. The screen returns to the special function menu screen.

## Operation procedures


Press the number keys as [007108], and press [ENT] to access Traverse Measurement Function. Then, use "1" number key to select "1. New observation" to proceed to STEP 1.

### Step 1 Inputting the instrument point coordinates (N, E, and Z) and the instrument height




\* At ②, If there is no need to enter a Z coordinate, leave the data as "000.000", or simply press the [CLR] key and then the [ENT] key. This stores a Z coordinate of "0".


### Step 2 Inputting the backsight point coordinates or the azimuth angle



### Step 3 Sighting the backsight point



## Step 4 Observation of the new points (P1 to Px)




- \* If the instrument is moved and a traverse route is to be measured, first select "New Observation", and then, after the instrument point is moved, select "Instrument Moved".
- \* When using traverse measurement while moving the instrument point, always measure the target which will serve as the next instrument point, and register it. Also, if several points are being measured at once, the point which has to be registered as the new point should be observed last of all, in order to reduce the chances of forgetting to register it.
- \* When "2. Instrument Moved" is entered, the coordinates of the new point stored here are automatically changed to the coordinates of the instrument point, and the coordinates of the instrument point are automatically changed to those of the backsight point. The data input as the prism height is also changed to the instrument height. If the current instrument height is different from the previous prism height, use STEP 1 of "2. Instrument Moved" to change the instrument height. If the height does not need to be changed, press the "↘" key to advance to the next page, and start from STEP 2.
- \* If the prism height ③ has been changed at STEP 4, go on to ④ and enter [Don't Store (NO)] to return to the beginning of STEP 4 and change the prism height.

# 36 Horizontal Angle Repeat Function Command No. 110


## General pictures of measurement

With the horizontal angle repeat function, the horizontal angle between the No.1 target (P1) and the No.2 target (P2) is measured number of N times, and the cumulative values and averaged values can be determined.

### General picture



## Operation procedures and operative illustrations




\* Pressing [ESC] key a couple of times interrupts the function. The screen returns to the special function menu screen.

# 38 Horizontal Angle Repeat Function Command No. 110

## Operation procedures

Press the number keys as [007110], and press [ENT] to access STEP 1 of Horizontal Angle Repeat Function.


### Step 1




### Step 2




\* When sighting P2, use the upper clamp and tangent screws.



\* When returning the telescope to P1, use the lower clamp and tangent screws. Never at the same time use the upper clamp and tangent screws.



\* When sighting P2, use the upper clamp and tangent screws.



\* The number of times (N) that the angle can be measured in this function is from 1 to 9.

\* The cumulative value for the horizontal angle can be a value  $-2700^\circ$  to  $+2700^\circ$ . If the value exceeds  $\pm 2000^\circ$ , a warning beep sounds.

\* When bringing the telescope back to P1, the following message will be displayed if the upper clamp and tangent screws are mistakenly used or if incorrect measurement is taken.


**\*NG!!  
AVG-ERROR  
REMEASURE**

Remeasurement is needed when the above message is on the display.

## General pictures of measurement





With the 3D cross section measurement function, prisms are placed at 2 points almost directly below the place to be measured, and these prisms are measured. The coordinates of the perpendicular plane formed along the straight line extending between the two prisms are determined, so that it is easy to measure the coordinates of locations where prisms can not be placed directly such as on the walls of objects being constructed, and cross sections of tunnels. With this type of measurement, the X and Z coordinates are measured, but the Y coordinate is fixed at 0.

## General picture





## Operation procedures and operative illustrations




\* Pressing [ESC] key a couple of times interrupts the function. The screen returns to the special function menu screen.


## Operation procedures

Press the number keys as [007111], and press [ENT] key to access STEP 1 of 3D Cross Section Measurement Function.


### Step 1 Observing the datum station



### Step 2 Observing in the X direction



### Step 3 Observing the target




\* Perpendicular planes are the only items that can be measured with the 3D cross section measurement function. Convex and concave sections of perpendicular planes cannot be measured.

# 42 REM Function Command No. 112


## General pictures of measurement

With REM measurement, a prism (base point) is set directly below the place to be measured, and by measuring the prism, the height to the target object can be measured. This makes it easy to determine the heights of electric power lines, bridge suspension cables, and other large items used in construction.

### General picture



## Operation procedures and operative illustrations




\* Pressing [ESC] key a couple of times interrupts the function. The screen returns to the special function menu screen.

# 44 REM Function Command No. 112


## Operation procedures

Press the number keys as [007112], and press [ENT] to access STEP 1 of REM function.

### Step 1 Observing the base point



### Step 2 Observing the target




## General pictures of measurement

With resection measurement, two known points (Points A and B) are measured in order to determine the coordinates of the instrument point.

The scaling function can also be used with the resection function.

### General picture




Point ZA: Z coordinate value of the new point obtained by measuring

Point ZB: Z coordinate value of the new point obtained by measuring

Difference(Z): Value (Point ZA) - (Point ZB)

# 46 Resection Function Command No. 113

## Operation procedures and operative illustrations




\* Pressing [ESC] key a couple of times interrupts the function. The screen returns to the special function menu screen.


## Operation procedures

Press the number keys as [007113], and press [ENT] to access STEP 1 of Resection function.


### Step 1 Inputting the instrument height



### Step 2 Inputting the Point A coordinates and the prism height



### Step 3 Inputting the Point B coordinates and the prism height






# 48 Resection Function Command No. 113

## Step 4 Observing Point A



## Step 5 Observing Point B




\* If the difference at ② in Step 5 is excessively large, do the measurement again.

## General pictures of measurement


In the direct stake check, the difference between the design values for a horizontal distance, calculated using inverse calculation from the coordinate values of a known point (Point A) and a target point (Point B), and the horizontal distance actually measured between A and B is displayed. The scaling function can also be used with the direct stake check.

### General picture



# 50 Direct Stake Check Function Command No. 114

## Operation procedures and operative illustrations




Pressing [ESC] key a couple of times interrupts the function. The screen returns to the special function menu screen.

## Operation procedures


Press the number keys as [007114], and press [ENT] to access STEP 1 of Direct Stake Check Function.

### Step 1 Inputting the coordinates for the instrument point (Point A)




\* The values for the Z coordinate are not directly related to this calculation, and can be omitted here (simply press [ENT] without entering a value).

### Step 2 Inputting the coordinates for the target point (Point B)



\* The Z coordinates may be omitted.


### Step 3 Observing the target point (Point B)




## General pictures of measurement

In the remote stake check function, the difference between the design values for a horizontal distance, calculated using inverse calculation from the coordinate values of two known points (Points A and B), and the horizontal distance actually measured between A and B is displayed. The scaling function can also be used with the remote stake check.

### General picture



## Operation procedures and operative illustrations




Pressing [ESC] a couple of times interrupts the function. The screen returns to the special function menu screen.

## Operation procedures


Press the number keys as [007115], and press [ENT] to access STEP 1 of Remote Stake Check Function

### Step 1 Inputting the coordinates for Point A



\* The values for the Z coordinate are not directly related to this calculation, and can be omitted here (simply press [ENT] without entering a value).

### Step 2 Inputting the coordinates for Point B




\* The Z coordinates may be omitted.

### Step 3 Observing Point A




### Step 4 Observing Point B



## General pictures of measurement

With offset station measurement, a PTS set on a center line is used for easy setting of the stake-out points to the left and right of the center line.


### General picture





# 56 Offset Station Function Command No. 116

## Operation procedures and operative illustrations




Pressing [ESC] key a couple of times interrupts the function. \* The screen returns to the special function menu screen.


## Operation procedures

Press the number keys as [007116], and press [ENT] to access STEP 1 of Offset Station Function.


### Step 1 Sighting the center station




### Step 2 Selecting either observation or input



### Step 3 Stake-out of the left station




### Step 4 Stake-out of the right station



## General pictures of measurement






With the area measurement function, the area is calculated and displayed in real time as each target point is measured, and the horizontal distance between two prisms is displayed as well.

### General pictures



\* When making the coordinate measurement by setting the direction angle to the backsight point, use the inverse azimuth/distance measurement function to set the direction angle of the backsight point.

## Operation procedures and operative illustrations




\* Pressing [ESC] key a couple of times interrupts the function. The screen returns to the special function menu screen.

# 60 Area Function Command No. 117

## Operation procedures


Press the number keys as [007117], and press [ENT] to access STEP 1 of the Area Function.

### Step 1 Inputting the instrument point coordinates



\* The values for the Z coordinate are not directly related to this calculation, and can be omitted here (simply press [ENT] without entering a value).

### Step 2 Observing the target




\* With area measurement, observation and calculation can be carried out for up to ten targets.

\* With area measurement, observation should be carried out in the same direction of rotation.

## Scaling Correction

"Scaling" as used here refers to scaling and perspective correction carried out as part of the measurement process among the special functions. It is effective only with coordinate stake-out, traverse measurement, inverse azimuth/distance calculation, direct stake check, remote stake check, and resection measurement. Of these, reverse perspective correction is carried out with coordinate stake-out, inverse azimuth/distance, direct stake check, and remote stake check.

\* When the unit is shipped from the factory, the correction coefficient is set to "1" and the elevation to "0", so that no correction is carried out. If correction is necessary, input the appropriate values for the scaling coefficient and the averaging elevation.



### 1. Perspective correction

Average(H)=Averaged on-site elevation

Input range: -9999.99 ~ +9999.99m

### 2. Scaling coefficient


Scaling=On-site scaling coefficient

Input range: +0.90000000 ~ +1.19999999

# 62 Scaling Function Command No. 118

## Operation procedures

Press the number key as [007118], and press [ENT] to access the Scaling Function.



## The Equation of Perspective Correction

\* The perspective correction for the scaling function is determined using the following equation.

### Perspective Correction Equation

This equation is used when the on-site slope distance is to be corrected to the distance for the horizontal value angle coordinates.

$$S_b = S_a (R/R + H)$$

S<sub>b</sub> : Horizontal distance (distance on surface of standard ovalshaped object)

S<sub>a</sub> : Horizontal distance (distance on surface of actual site)

R : Averaged datum station for radius of earth (6370 km(20,898,906.21ft))

H : Average on-site elevation (input value)

$$S_c = m (S_b)$$

S<sub>c</sub> : Horizontal distance (distance between horizontal angle coordinates)

m : Scaling coefficient (input value)

S<sub>b</sub> : Horizontal distance (distance on surface of standard ovalshaped object)

This horizontal distance S<sub>c</sub> is used to calculate the coordinates.

### Reverse Perspective Correction Equation

This equation is used when the distance between horizontal angle coordinates is being corrected to a horizontal distance on the actual site.

$$S_a = S_c / m \times (1 + H/R)$$

S<sub>a</sub> : Horizontal distance (distance on actual site)

m : Scaling coefficient (input value)

S<sub>c</sub> : Horizontal distance (distance between horizontal angle coordinates)

R : Averaged datum station for radius of earth (6370 km(20,898,906.21ft))

H : Average on-site elevation (input value)





**PENTAX®**

**ASAHI PRECISION CO., LTD.**

1-1-21, Shirako, Wako-shi,  
Saitama-ken, 351-0101, Japan

Tel: +81-48-461-5377

Fax: +81-48-466-3979



The CE marking assures that  
this product complies with  
the requirements of the EC  
directive for safety.

08.1991 First edition  
03.12.1998 Fourth edition

**TS001B04E**

Printed in Japan